



Zipper Access Doors

Static Intercept Access doors:

These Static Intercept access doors allow you to look inside your shrink-wrapped cover to periodically inspect your Product it also allows you to open the package to replace desiccant if necessary, You will find many uses for these doors

Installation:

To install these access doors (1) find where you want to put the door (2) peel the pink liner from the double tape on the backside of the door (3) stick the door onto the shrinkwrap (AFTER THE FILM HAVE BEEN SHRUNK) (4) tape all 4 sides with 4" sealing tape (5) zip the door open and cut a hole in the shrink wrap cover (6) zip the door closed (you can purchase the tape from us)

The diagrams illustrate the installation process for two types of zipper access doors:

- Static Intercept:** Shown in the first and third diagrams. A pink liner is peeled back from the top-left corner of the door, and the door is then sealed to the shrinkwrap.
- Corrosion Intercept:** Shown in the second and fourth diagrams. An orange liner is peeled back from the top-left corner of the door, and the door is then sealed to the shrinkwrap.

Zipper Access Doors are available in both Static and Corrosion Intercept. At the present we do not stock intercept zipper doors, they will be made to your specs. We can deliver in just a couple days. When ordering zipper doors you need to give us the size opening you want

